




HP-1814
HP-1838



HP-1513
HP-1536



HP-1838H
HP-1838HT






HP-1536H
HP-1536HT

Model	Description	Dia.	Watt.	Volt.	Heating Elements	Outlet Wires	Controller
HP-1814	Standard Hotplate	180mm	1500w	230v	1	2	
HP-1838	Standard Hotplate	180mm	1500w	230v	3	4	
HP-1838H	Rapid Hotplate	180mm	2000w	230v	3	4	
HP-1838HT	Rapid Hotplate	180mm	2000w	230v	3	4	Thermostat Inside
HP-1513	Standard Hotplate	145mm	1000w	230v	1	2	
HP-1536	Standard Hotplate	145mm	1000w	230v	3	4	
HP-1536H	Rapid Hotplate	145mm	1500w	230v	3	4	
HP-1536HT	Rapid Hotplate	145mm	1500w	230v	3	4	Thermostat Inside



Adres:
Turgut Özal Bul. No:50
Kazan, 06980
Ankara / TÜRKİYE

Telefon: +90 (312) 814 51 20
Faks: +90 (312) 814 51 29
E-Posta: balcik@balcik.com.tr
Web: <http://www.balcik.com.tr>

**HP-1814**
HP-1838**HP-1513**
HP-1536**HP-1838H**
HP-1838HT**HP-1536H**
HP-1536HT

Model	Description	Dia.	Watt.	Volt.	Heating Elements	Outlet Wires	Controller
HP-1814	Standard Hotplate	180mm	1500w	230v	1	2	
HP-1838	Standard Hotplate	180mm	1500w	230v	3	4	
HP-1838H	Rapid Hotplate	180mm	2000w	230v	3	4	
HP-1838HT	Rapid Hotplate	180mm	2000w	230v	3	4	Thermostat Inside
HP-1513	Standard Hotplate	145mm	1000w	230v	1	2	
HP-1536	Standard Hotplate	145mm	1000w	230v	3	4	
HP-1536H	Rapid Hotplate	145mm	1500w	230v	3	4	
HP-1536HT	Rapid Hotplate	145mm	1500w	230v	3	4	Thermostat Inside



Adres:
Turgut Özal Bul. No:50
Kazan, 06980
Ankara / TÜRKİYE

Telefon: +90 (312) 814 51 20
Faks: +90 (312) 814 51 29
E-Posta: balcik@balcik.com.tr
Web: <http://www.balcik.com.tr>